

# Digital Adapter



Included in this kit:



Coaxial Cable



HDMI Cable



Power Cord



Remote Control



Two AAA Batteries




Adhesive Fasteners

## Step 1

### Connect Adapter to Your TV

- A Turn off your TV, and then disconnect the coax cable from it. Leave the other end connected to your coax outlet.
- B Connect the coax cable that you disconnected from your TV to the digital adapter.
- C If your TV has an HDMI port: Connect the HDMI cable to the digital adapter, and then connect the other end to your TV.  
If your TV doesn't have an HDMI port: Connect the coax cable to the digital adapter, and then connect the other end to your TV.
- D Turn on your TV, and then select the correct source.
  - If you connected the HDMI cable to the digital adapter: Use INPUT or SOURCE on your TV to select the appropriate HDMI source.
  - If you connected the coax cable to the digital adapter: Set the CH 3/4 switch on the digital adapter to channel 3 or 4, and then set your TV to the same channel.



## Step 2

### Connect Digital Adapter to Power

- A Connect the power cable to the digital adapter, and then connect the other end to an electrical outlet. If you have additional digital adapters, connect them to your other TVs.  
A green light on the front of the digital adapter should turn on and blink. It may take up to 20 minutes to download any updates. If the light doesn't turn on, make sure the power cable is properly connected.
- B If your TV displays a picture, the digital adapter is already activated. If a message appears, continue to step 3.

## Step 3

### Activate Digital Adapter

- A Call (855) 286-1736. If prompted, enter the 10-digit phone number associated with your account, and then say "Activate."
- B Keep your equipment connected during activation (about 15-30 minutes). After activation is complete, your TV will automatically display a picture.

## Step 4

### Program Your Remote

- A Visit [spectrum.net/digitaladapter](https://spectrum.net/digitaladapter) from your smartphone or computer for remote programming instructions and more info about the digital adapter.